


Callisto Assembly Instructions

Fittings Included	Assembly Instructions		Tools Required
Workstation		<ol style="list-style-type: none">1 Remove plate from each leg assembly using Allen Key2 With legs upright, push beam into leg assemblies, locating the dowel pins into the holes in beam3 Secure legs to beam using plates and allen screws previously removed4 Evenly fit plastic cable holders to beam on chosen side	Flat Screwdriver
Screws		<p>Workstations supplied with a corner leg (e.g. Cresents) attach corner leg by inserting threaded bar through corner of beam - secure with 10mm nut</p> <ol style="list-style-type: none">5 With workstation top face down, on a flat surface, fix the frame assembly to top with rail screws6 Stand the workstation upright and clip cable covers to legs and clip 'e' covers in end of beam	Pozi Screwdriver Allen Key (Supplied)